




1. Unlock case with keys provided and remove faceplate.



2. Feed cable through the stand and plug in your tablet while placing it into the case.




3. Place tablet into case, plug in charging cable and place faceplate back on and lock.




Optional Cable Cutout

Unscrew existing closed cable cutout and install the open cable cutout included with stand.



Optional Rotation Lock

Place case on the pole in desired rotation and screw lock screw as shown to lock rotation.



Optional Tilt Adjustment Lock

Using Allen key provided, tighten screw at desired angle to lock in position.

For more information or to contact our sales & customer support team please click on the links below:

[Contact Us](#)

[Warranty & Returns](#)

[Shipping](#)