


Note: Ensure that surface of tablet is clean with provided cleaning cloth.

Remove protective film from the adhesive on the backplate and stick the backplate to the center of the tablet.

### ADHESIVE Anchor Point

2a



Remove protective film and apply the double sided adhesive to the Anchor Point and apply firm pressure to the suitable surface area.


### SCREW Anchor Point

2b




Use suitable screws for your mounting surface and screw onto surface using the two inner holes of the Anchor Point.


3



Remove protective film from adhesive under the Cover Plate and apply firmly onto Anchor Point base.

**4**

Feed the looped end of the Boss Cable through the Anchor Point.

**5**

Feed the lock end of the cable through the loop hole of the cable creating an anchor knot.

### Cable feed OVER Stand

**6a**

Feed the Boss Cable over the stand.

### Cable feed THROUGH stand

**6b**

Feed the Boss Cable through the stand in the hole provided.

**7**

Use the provided key to lock the Boss Cable to the Tablet Plate on the tablet.